

WORK LIGHT INSTALLATION GUIDE

Art. nr. 581445, 581480

THANK YOU FOR PURCHASING OUR PRODUCTS FOR YOUR VEHICLE

Please read through all of these Instructions before proceeding with the installation. We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

1. Utility Range


Most demanding work environments, including material handling, construction, agricultural, forestry, mining and the off road equipment and truck application.


2. Installation


- Firstly, verify all the components and accessories involved in the package.
- Testing lamp whether it is on work before installation. Blue wire: Red position light Yellow wire: Amber position light White wire: White position light Red wire: + Positive Black wire: - Negative
 - Bracket mounting way Refer to drawing as below.
- Connect power line to the corresponding power connector. Ensuring polarity is correct.

3. Notes

- Do not use if the lamp housing and lens is broken when new product takes out of the package.
- Must power off when installing.







Mounting instructions for ECE R148

